
AUDIO & VISUAL SYSTEM


COMPONENTS

6709C–01



P

I31116


Front No.2
Speaker Assy
Power Point
Socket Cover
Power Point
Socket Assy
Cigarette Lighter Assy
Antenna
Ornament
Motor Antenna
Control Relay
Antenna
Nut
w/ Holder
Antenna
Assy
Antenna Cord
Sub–assy
Power Point
Socket Assy RR
Power Outlet
Socket Cover RR
Front No.1
Speaker Assy
Rear Speaker Assy
Disc Player
Bracket No.2
Navigation
ECU
Disc Player
Bracket
Navigation Antenna
Assy
P
I31594