72073–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Power seat does not operate	1. Front power seat switch 2. PWR SEAT fuse 3. Wire harness	72–3 – –
Power seat does not slide	1. Front power seat switch 2. Front slide power seat motor assy (Slide) 3. Wire harness	72–3 72–3 –
Front vertical of the power seat does not operate (Driver's seat only)	1. Front power seat switch 2. Front up, down power seat motor assy (Front vertical) 3. Wire harness	72–3 72–3 –
Rear lifter of the power seat does not slide operate (Driver's seat only)	1. Front power seat switch 2. Power seat motor assy (Rear vertical) 3. Wire harness	72–3 72–3 –
Power seat does not reclining	1. Front power seat switch 2. Power seat motor assy (Reclining) 3. Wire harness	72–3 72–3 –