
FRONT SEAT ASSEMBLY LH (MANUAL SEAT TYPE)

72077–01

COMPONENTS

In RHD vehicle, look in the same location as in the LHD vehicle.



N·m (kgf·cm, ft·lbf) : Specified torque ◆ Non–reusable part

B57291