7207C–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Seat heaters do not operate	1. SEAT HTR fuse	–
	2. Front seat cushion heater assembly LH	72–26
	3. Front seat cushion heater assembly RH	72–26
	4. Front seat back heater assembly LH	72–26
	5. Front seat back heater assembly RH	72–26
	6. Seat heater switch	72–26
	7. Wire harness	–