74048–02

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Sliding roof system does not operate	1. PWR NO.1 fuse	–
	2. Sliding roof motor switch	74–5
	3. Sliding roof drive gear	74–2
	4. Wire harness	74–2
	5. Faulty sliding of sliding roof	–
Sliding roof operation is abnormal	1. Sliding roof motor switch	74–5
	2. Sliding roof drive gear	74–2
	3. Wire harness	–
Sliding roof system stops operation half way (No foreign object is in the motor)	1. Sliding roof motor switch	74–5
	2. Sliding roof drive gear	74–2
	3. Wire harness	–