0300Z–05

TORQUE SPECIFICATION

Part Tightened	N·m	kgf·cm	ft·lbf
Transmission case x Manual transaxle case	29	296	21
Manual transaxle case x Transmission case	29	296	21
Bearing retainer RR x Transmission case	42	428	31
Manual transaxle case receiver x Manual transaxle case	7	71	62 in.·lbf
Gear shift head No.1 x Gear shift fork shaft No.2	24	245	18
Gear shift fork No.1 x Gear shift fork shaft No.1	24	245	18
Reverse shift arm bracket x Manual transaxle case	17	173	13
Reverse restrict pin plug x Transmission case	13	133	9.6
Oil receiver pipe No.1 x Transmission case	17	173	13
Oil receiver pipe No.2 x Transmission case	17	173	13
Clutch tube bracket x Transmission case	17	173	13
Reverse idler gear shaft bolt x Transmission case	30	306	22
Shift detent ball plug x Manual transaxle case	25	250	18
Transmission clutch hub No.3 gear shift fork shaft x input shaft	24	245	18
Manual transmission output rear set nat. x Output shaft	123	1,254	91
Drain (MTM) plug sub–assy x Transmission case	49	500	36
Manual transmission filler plug x Transmission case	49	500	36
Back up lamp switch assy x Transmission case	40	408	30
Manual transmission breather plug x Transmission case	49	500	36
Lock ball assy No.1 x Transmission case	29	296	21
Control shift cover x Transmission case	20	204	15
Control shift lever x Shift & select lever assy	6.4	65	57 in.·lbf
Selecting bell crank assy x Transmission case	20	204	15
Speedometer driven hole cover x Transmission case	5.5	56	48 in.·lbf
Selecting bellcrank support x Selecting bellcrank No.2 plate washer	12	122	9
Release fork support x Manual transaxle case	47.1	480	35
Front differential ring gear x Front differential case	106	1,081	78