

F RELAY LOCATIONS

: Instrument Panel J/B	LHD : Lower Finish Panel (See Page 21)
	RHD : Behind the Glove Box (See Page 21)




Main Body ECU
IH
(from Instrument Panel Wire)
IG
(from Instrument Panel Wire)
II
(from Instrument Panel Wire)
30A POWER
(for High Current)
30A P/SEAT
(for High Current)

F RELAY LOCATIONS

: Instrument Panel J/B	LHD : Lower Finish Panel (See Page 21)
	RHD : Behind the Glove Box (See Page 21)

