

H1
H3
H10
H8
H7
J1
J3
J5
J6
I2
I1
I4
I9
I7
I6
K1
K6
K3
K5

H 1 Speaker (Front Door RH)
H 3 Outer Rear View Mirror (RH)
H 3 Outer Rear View Mirror (RH)
H 3 Outer Rear View Mirror (RH)
H 7 Courtesy Lamp (Front Door RH)
H 8 Door Lock Assembly (Front RH)
H 10 Power Window ECU (Front RH)

I 1 Speaker (Front Door LH)
I 2 Outer Rear View Mirror (LH)
I 2 Outer Rear View Mirror (LH)
I 2 Outer Rear View Mirror (LH)
I 2 Outer Rear View Mirror (LH)
I 4 Power Window Regulator Motor (Front LH)
I 6 Courtesy Lamp (Front Door LH)
I 7 Door Lock Assembly (Front LH)
I 9 Power Window SW (Front LH)

J 1 Power Window SW (Rear RH)
J 3 Power Window Regulator Motor (Rear RH)
J 5 Door Lock Assembly (Rear RH)
J 6 Courtesy Lamp (Rear Door RH)

K 1 Power Window SW (Rear LH)
K 3 Power Window Regulator Motor (Rear LH)
K 5 Door Lock Assembly (Rear LH)
K 6 Courtesy Lamp (Rear Door LH)

H 1
White




H 3
White




(2AZ-FE)

H 3
White



(2GR-FE w/ Seat Position Memory)

H 3
White




(2GR-FE w/o Seat Position Memory)


H 7
White



H 8
White




H 10
White



I 1
White




I 2
White




(Before Jun. 2009 Production 2GR-FE w/ Seat Position Memory)

I 2
White



(2GR-FE w/o Seat Position Memory)

I 2
White



(From Jun. 2009 Production 2GR-FE w/ Seat Position Memory)

I 2
White



(2AZ-FE)


I 4
Black




I 6
White




I 7
White



I 9
White




J 1
White




J 3
Black




J 5
White




J 6
White




K 1
White



K 3
Black



K 5
White



K 6
White

