




* 2:w/ Smart Entry & Start System
* 3:w/ Parking Assist (TOYOTA Parking Assist-Sensor)
* 4:w/o Parking Assist (TOYOTA Parking Assist-Sensor)
* 5:2GR-FE
* 6:2AZ-FE
* 11:Before Feb. 2010 Production
* 12:From Feb. 2010 Production

E 38 A/C Amplifier
E 39 Blower Motor
E 40 Junction Connector
E 41 Junction Connector
E 42 Junction Connector
E 43 Junction Connector
E 44 Junction Connector
E 45 Junction Connector
E 46 Junction Connector
E 48 Junction Connector
E 49 Junction Connector
E 50 ID Code Box
E 51 Steering Lock ECU
E 52 Power SW
E 56 Electrical Key Oscillator (Console)
E 57 Shift Lock Control ECU
E 58 Certification ECU
E 62 Junction Connector
E 63 Junction Connector
E 64 Headlamp Leveling SW
E 69 AFS OFF SW
E 70 Gateway ECU
E 73 Back Sonar SW
E 74 Rear Sunshade SW
E 78 Junction Connector
E 79 Junction Connector
E 80 Junction Connector
E 89 Junction Connector
E 90 Stop Lamp Control Relay
E 96 Junction Connector
E 98 AFS OFF SW
E 99 Electrical Key Oscillator (Console)


E 38
White




E 39
Black




E 40
White




E 41
Blue




E 42
White




E 43
White




E 44
Black




E 45
Black




E 46
Blue




E 48
White




E 49
Black




E 50
White




E 51
Black



E 52
Black




E 56
White




E 57
White




E 58
White




E 62
Gray




E 63
Brown




E 64
Black




E 69
Gray




E 70
White



E 73
Black



E 74
Black




(LHD 2GR-FE, 2AZ-FE)


E 78
White




E 79
White




E 80
Black




E 89
White




E 90
Black



E 96
White



E 98
Gray



E 99
White

