

Roof Wire
E1
Instrument Panel Wire Assembly
Instrument Panel No.3 Wire
E3
Instrument Panel No.2 Wire
Engine Room Main Wire
Front Door LH Wire
A3
Floor Wire
A6
Floor No.2 Wire
Front Door RH Wire
F3
E2
Floor Wire
Floor No.2 Wire
Instrument Panel Wire
F2
F1