

(*1)
E5
E9
E6
E7
E1
E2
E11
E15
E27
* 1:w/o Smart Entry & Start System
* 2:w/o Seat Position Memory
E14
E24
E23
E25
E13
E8
E26
E29
E28
E33
E35
E31
E34
E32
(*1)
E30
E20
E19
E18
E16
E17
E21
E22
E4
E3
(*2)
E10

| | | |
|---|---|---|
| E | 1 | Diode (Door Courtesy Rear LH) |
| E | 2 | Diode (Door Courtesy Rear RH) |
| E | 3 | Outer Mirror SW |
| E | 4 | Headlamp Cleaner SW |
| E | 5 | Diode (Door Courtesy Front LH) |
| E | 6 | Main Body ECU |
| E | 7 | Main Body ECU |
| E | 8 | Main Body ECU |
| E | 9 | Main Body ECU |
| E | 10 | DLC3 |
| E | 11 | Automatic Light Control Sensor |
| E | 11 | Automatic Light Control Sensor |
| E | 13 | VSC Warning Buzzer |
| E | 14 | Turn Signal Flasher |
| E | 15 | Transponder Key ECU |
| E | 16 | Airbag Squib (Steering Wheel Pad) |
| E | 17 | Steering Sensor |
| E | 18 | Spiral Cable |
| E | 19 | Windshield Wiper SW Assembly |
| E | 20 | Windshield Wiper SW Assembly |
| E | 21 | Headlamp Dimmer SW Assembly |
| E | 22 | Unlock Warning SW |
| E | 23 | Ignition SW |
| E | 24 | Key Interlock Solenoid |
| E | 25 | Transponder Key Amplifier |
| E | 26 | Windshield Wiper Relay |
| E | 27 | A/C Room Temp. Sensor |
| E | 28 | Cigarette Lighter |
| E | 29 | Power Outlet Socket (Front) |
| E | 30 | Airbag Sensor Assembly Center |
| E | 31 | Transmission Control SW |
| E | 32 | Shift Lock Control ECU |
| E | 33 | Parking Brake SW |
| E | 34 | Yaw Rate Sensor |
| E | 35 | Power Outlet Socket (Rear) |


E 1
Black





E 2
Black




E 3
White





E 4
White





E 5
Black





E 6
White





E 7
White





E 8
White





E 9
White




E 10
Black





E 11
Black




(Manual A/C Except RHD 2GR-FE)

E 11
Blue




(Automatic A/C Except RHD 2GR-FE)


E 13
Black





E 14
Black





E 15
White




E 16
Yellow





E 17
Black





E 18
Black





E 19
White




E 20
White





E 21
White





E 22
White





E 23
White




E 24
Black





E 25
Black




E 26
White





E 27
Black





E 28
White





E 29
White





E 30
Yellow




E 31
White





E 32
White




E 33
White




E 34
Black




E 35
White

