
■ FRONT OCCUPANT DETECTION SENSOR (Except Australian Models)

The occupant detection sensor, which is enclosed in the seat cushion of the front passenger seat, is used to detect whether or not the front passenger seat is occupied.
This sensor, which is shaped as illustrated below, consists of a construction in which two sheets of electrodes sandwich a spacer. When the occupant is seated, the electrode sheets come in contact with each other through the hole that is provided in the spacer portion, thus enabling the current to flow.
Thus, the sensor detects whether or not an occupant is seated in the front passenger seat.



View from Upside

02KBE88Y