

■ PRECAUTION FOR PRE-CRASH SAFETY SYSTEM OPERATION

- When the millimeter wave radar sensor detects an object in front under the conditions described below, the distance control ECU may determine that a collision is unavoidable, and operate the pre-crash safety system. However, this is not abnormal.


Object on road surface at corner entrance (Guard Rail, Street Light, Sign, Signboard)




Opposing traffic vehicle during cornering



Opposing traffic at intersection



Narrow Iron Bridge



Metal object, steel plate, or bump on road surface

02KBE62Y

- The millimeter wave radar sensor might not be able to detect the following objects as collision objects:

Objects that cannot be detected	Plastic items (Safety Cones, etc.), etc.
Objects that cannot be detected in a stable manner	People, Bicycles, Motorcycles, Trees, Animals, Snow Fence, etc.