
POWER DISTRIBUTOR

■ DESCRIPTION

- The power distributor is built into the engine room relay block, and uses a small mechanical relay and semiconductor relay for a compact and lightweight design.



01YBE09Y

- The components of the power distributor are shown below.

Component	Relay
Mechanical Relay	● Horn Relay ● A/F Relay ● Security Horn Relay ● EFI Relay ● Circuit Opening Relay ● Headlight Relay (RH)*1 ● Headlight Relay (LH)*1
Semiconductor Relay	● Headlight HI Beam Relay ● Headlight Relay (RH)*2 ● Headlight Relay (LH)*2

*1: Models with halogen type headlight
*2: Models with HID type headlight