
■LIGHT TURN-OFF SYSTEM

- The light turn-off system is used to prevent the driver from leaving the vehicle with the headlights, fog lights, parking lights, taillights, or license plate lights on.
- When all of the following conditions are met, the exterior lights turn off.
  - – Ignition switch is turned from ACC or ON to OFF.
  - – The light control switch is in any position except OFF.
  - – The fog light switch is ON. (Only for fog lights)
  - – Driver's door is opened after driver's doors have been closed.

▶ System Diagram ◀



01ZBE13P

*: Rear fog light settings vary depending on the destination package. For details, see the equipment list in Model Outline.