# ENGINE IMMOBILIZER SYSTEM

## ■ DESCRIPTION

- The engine immobilizer system compares the ID code that is registered in the transponder key ECU with the ID code of the transponder chip that is embedded in the ignition key. The system unsets if these ID codes match. Thus, the transponder key ECU and the engine ECU communicate with each other to authorize fuel injection and ignition, enabling the engine to start.
- This system is standard equipment on all models.

**Service Tip**

When replacing the transponder key ECU or making a new ignition key, and the key's recognition code must be registered.

- When the transponder key ECU has been replaced, the automatic registration mode begins. At this time, the total number of keys that can be registered is three (master key: two, sub key: one).
- The recognition code of additional keys must be registered. At this time, the total number of keys that can be registered is eight (master key: five, sub key: three).

For details, see the Camry Repair Manual (Pub. No. RM0260E).