
REAR WINDOW DEFOGGER SYSTEM

■ DESCRIPTION

- The rear window defogger system uses the heater wire on the rear window glass to defog the rear window glass.
- This system is standard equipment on all models.
- The rear window defogger system operates at the same time as the heater function of the outside rear view mirror.
- This system is activated when the ignition switch is turned on and the rear window defogger switch is pushed. This switch is provided with a timer function to turn off the defogger and mirror heater after approx. 15 minutes. The operation period of the timer may extend to approx. 45 minutes depending on the circumstances of the outside air temperature and vehicle speed.

▶ System Diagram ◀



026BE72Y