■ HANDS-FREE FUNCTIONS (Models with Navigation with AV System)

The Bluetooth® hands-free system installed on the models with navigation with AV system has the following functions. However, for safety, some functions may not be selectable when the vehicle is being driven.

Function		Outline
Call with Bluetooth® phone	By dial	The user can call by inputting a telephone number.
	By phonebook	The user can call by using the phonebook data that have been transferred from the user's cellular phone. The user can register up to 1000 numbers in the phonebook.
	By dialed numbers	The user can call by selecting a previously dialed number. The system remembers up to five dialed numbers. If more than five numbers have been dialed, the oldest number will no longer be remembered.
	By received calls	The user can call by selecting the telephone number of a received call. When a call is received, the system will remember the last five numbers. If more than five calls have been received, the oldest number will no longer be remembered.
	By speed dial	The user can call by using registered telephone numbers that the user selected from the phonebook, dialed numbers or received calls.
	By voice recognition (Dialing by name)	The user can call by giving a name registered in the phonebook.
	By voice recognition (Dialing by phone number)	The user can call by giving a desired number.
	By POI (Point of Interest) call	The user can call by operating a switch when "Call" is displayed on the screen from navigation system.
Receive with Bluetooth® phone		When a call is received, the receive screen is displayed with a sound.
Talk on the Bluetooth® phone		While user is talking on the phone, the talking screen is displayed.
Change the settings of the Bluetooth® phone	Registering the speed dial	The user can register the desired telephone number from the phonebook, dialed numbers or received calls. Up to 17 speed dial numbers can be registered.
	Setting the volume	The user can set the volume.
		Automatic volume settings for high speed: When the vehicle speed is over 80 km/h (50 mph), the volume automatically increases by 3 dB from the volume set by the user. When the vehicle speed decreases to 70 km/h (44 mph) or lower, the volume returns to the previous volume setting.
		Initializing the settings: The user can initialize the settings.
	Setting the screen	Receiving call display: The user can select the method of the receiving call display.
		Auto answer: When a call is received, the display automatically changes to the talking screen and user can start to talk on the phone (without touching any switch) after a preset time.
		The Bluetooth® connection status at startup: When the user turns the power source to ACC or IG-ON and the Bluetooth® is automatically connected, the connection check is displayed.
		Initializing the settings: The user can initialize the settings.

(Continued)

Function		Outline
Change the setting of the Bluetooth® phone	Setting the phonebook	Registering phone number: The user can register phone numbers in the phonebook.
		Transferring a telephone number: The user can transfer the telephone numbers from the user's Bluetooth® phone to the system. Up to 1,000 data (up to 2 numbers per entry) can be registered in the phonebook.
		Registering the phonebook data: The user can register the phonebook data.
		Editing the name: If no name has been inputted, the number is displayed.
		Editing the phone number: The user can register a phone number in "TEL1" and "TEL2" separately. Up to 2 numbers per phonebook entry can be registered.
		Selecting the group: The user can set a group for a contact. It will then be easier for the user to find this contact when needed, by using the grouping display.
		Setting the voice recognition: The user can set the voice recognition. Up to 20 numbers can be registered to allow voice recognition.
		Adding data to the phonebook: The user can add data to the phonebook.
		Editing the data: The user can edit the registered data.
		Deleting the data: The user can delete the data.
		Deleting all the phone data: The user can delete all the phone data.
		Registering a group name: The user can register 20 groups
		Selecting a group icon: The user can select the desired icon.
		Editing a group name: The user can input the name with the software keyboard.
		Deleting a group name: The user can delete the group names individually or all at once.
		Deleting the log data: The user can delete the log data individually or all at once.
Change the setting of the Bluetooth® phone	Setting the security	By setting the security, the user can prevent people from using some functions of the hands-free system. It is useful when the user leave their car with a hotel or valet parking or the user doesn't want others to see the data that the user has registered.
		Changing the security code: The security code is 4 digits and the default is "0000". Choose a new code that is hard for other people to guess.
		Phone book lock: The user sets the phonebook lock.
		Initializing the security code: The user can initialize the settings.

(Continued)

Function		Outline
Set a Bluetooth® phone	Enter the Bluetooth® phone	In order to use hands-free function of a Bluetooth® phone, it is necessary to register it in the audio head unit. Once a phone is registered, the hands-free function becomes available automatically. The user can register up to 6 Bluetooth® phones.
	Select the Bluetooth® phone	When two or more registered Bluetooth® phones are in the cabin, it is necessary to select which phone to use to prevent the lines from being crossed. Only the selected phone is available for use as a hands-free phone. The phone registered last is automatically selected.
	Indicate and change Bluetooth® information	The user can set, change and initialize the information of the Bluetooth® phone displayed on the screen.
	Deleting a Bluetooth® phone	A registered Bluetooth® phone can be unregistered from the multi display.
	Displaying theinformation of the Bluetooth® phone user delete	The user can display the information of the Bluetooth® phone before he/she deletes it and he/she can ensure that the telephone that he/she will delete is correct one.

4. Hands-free Functions (Models without Navigation with AV System)

The Bluetooth® hands-free system installed on the models without navigation with AV system has the following functions. However, for safety, some functions may not be selectable when the vehicle is being driven.

Function		Outline
Call with Bluetooth® phone	By phonebook	The user can call by using the phonebook data that have been transferred from the user's cellular phone.
	By dialed numbers	The user can call by selecting a previously dialed number (voice recognition is also available). The system remembers up to 5 dialed numbers. If more than 5 numbers have been dialed, the oldest number will no longer be remembered.
	By received calls	The user can call by selecting the telephone number of a received call (voice recognition is also available). When a call is received, the system will remember the last five numbers. If more than five calls have been received, the oldest number will no longer be remembered.
	By speed dial	The user can call using the registered phone number by pressing the function buttons (1 to 6) of the audio head unit.
	By voice recognition (Dialing by name)	The user can call by giving a name registered in the phonebook.
	By voice recognition (Dialing by phone number)	The user can call by giving a desired number.
Receive with Bluetooth® phone		When a call is received, the phone number or registered caller name is displayed on the audio head unit LCD with an audio signal.
Talk on the Bluetooth® phone		While the user is talking on the phone, the phone number or registered caller name is displayed on the audio head unit LCD.
Change the settings of the Bluetooth® phone	Setting the phonebook	Transferring a telephone number: The user can transfer the telephone numbers from the user's Bluetooth® phone to the system.
		Registering phone number: The user can register phone numbers using the following methods - Voice recognition - Using dialed numbers and received calls - Inputting phone numbers using the control knob of the audio head unit Up to 20 data can be registered in the phonebook.
		Add entry: The user can register voice recognition data for a maximum 20 registered phone numbers. The user can initialize the settings.
		Change Name: The user can change the registered voice recognition data.
		Delete entry: The user can delete the registered their voice recognition data.
		Delete speed dial: The user can delete the speed dials registered to the function buttons (1 to 6) of the audio head unit.
		List Names: The user can change or delete the voice recognition data, or can call using certain voice recognition data by selecting that data while the system is reading it out.

(Continued)

Function		Outline
Change the settings of the Bluetooth® phone	Registering the speed dial	The user can register a maximum of 6 speed dials to the function buttons (1 to 6) of the audio head unit by selecting the desired phone numbers from the voice recognition registration. The user can initialize the settings.
	Setting the volume	The user can set the volume.
		Automatic volume settings for high speed: When the vehicle speed is over 80 km/h (50 mph), the volume automatically increases by 3 dB from the volume set by the user. When the vehicle speed decreases to 70 km/h (44 mph) or lower, the volume returns to the previous volume setting. The user can initialize the settings.
	Setting the security	By setting the security, the user can prevent people from using some functions of the Hands-free system. It is useful when the user leaves their car with a hotel or valet parking or the user doesn't want others to see the data that the user has registered.
		Changing the security code: The security code is 4 digits. Choose a new code that is hard for other people to guess.
		Phone book lock: The user sets the phonebook lock.
		Initializing the security code: The user can initialize the settings.
Set a Bluetooth® phone	Enter the Bluetooth® phone	In order to use hands-free function of a Bluetooth® phone, it is necessary to register it in the audio head unit. Once a phone is registered, the hands-free function becomes available automatically. The user can register up to 6 Bluetooth® phones from a maximum of 6 numbers.
	Select the Bluetooth® phone	When two or more registered Bluetooth® phones are in the cabin, it is necessary to select which phone to use to prevent the lines from being crossed. Only selected phone is available for use as a hands-free phone. The phone registered last is automatically selected.
	Indicate Bluetooth® information	The user can check the information of the Bluetooth® phone on the audio head unit LCD.
	Change the passkey	The user can change the pass key on the audio head unit LCD.
	Deleting a Bluetooth® phone	The user can delete the registered Bluetooth® phone.