THEFT DETERRENT SYSTEM

■ DESCRIPTION

The warning methods have been changed as follows:*

*: Only for European models

Warning Method	Hazard Light	Flashing
	Vehicle Horn	Sound (approx. 0.4 seconds cycles)
	Security Horn	Sound (approx. 0.4 seconds cycles)
	Door Lock Motor	Locking
Warning Time		30 seconds

■ SYSTEM DIAGRAM

▶ Models With Entry and Start System ◀

