




- Q 1 Vanity Lamp SW (LH)
- Q 2 Vanity Lamp SW (RH)
- Q 3 Inner Rear View Mirror
- Q 4 Rain Sensor
- Q 6 Overhead J/B
- Q 7 Vanity Lamp (LH)
- Q 8 Vanity Lamp (RH)
- Q 9 Room Lamp (Center)
- Q 10 Map Lamp (RH)
- Q 11 Map Lamp (LH)
- Q 12 Sliding Roof Control ECU and Motor
- Q 13 Microphone
- Q 14 Inner Rear View Mirror

- S 1 License Plate Lamp (RH)
- S 2 Rear Combination Lamp (RH)
- S 3 Rear Combination Lamp (LH)
- S 4 License Plate Lamp (LH)
- S 5 Door Lock Assembly (Luggage)
- S 6 Luggage Compartment Door Lock Cylinder
- S 10 Turn Signal Lamp (Rear LH)
- S 11 Rear Combination Lamp (LH)
- S 12 Rear Combination Lamp (RH)
- S 13 Turn Signal Lamp (Rear RH)
- S 15 Junction Connector
- S 16 Junction Connector
- S 17 Rear Clearance Warning ECU Assembly
- S 18 Luggage Compartment Door Lock Cylinder
- S 19 Luggage Electrical Key SW , Television Camera
- S 20 Electrical Key Oscillator (Outside Luggage Room)


























- W 1 Door Outside Handle (Front RH)
- W 2 Electrical Key Oscillator (Front Door RH)

- X 1 Door Outside Handle (Front LH)
- X 2 Electrical Key Oscillator (Front Door LH)

- j 1 No.1 Ultrasonic Sensor (Rear Center LH)
- j 2 No.1 Ultrasonic Sensor (Rear Center RH)
- j 3 No.1 Ultrasonic Sensor (Rear Corner LH)
- j 4 No.1 Ultrasonic Sensor (Rear Corner RH)

- k 1 No.1 Ultrasonic Sensor (Rear Corner RH)
- k 2 No.1 Ultrasonic Sensor (Rear Center RH)
- k 3 No.1 Ultrasonic Sensor (Rear Center LH)
- k 4 No.1 Ultrasonic Sensor (Rear Corner LH)

Position of Parts in Body <LHD>



Position of Parts in Body <LHD>

