
RADIATOR UPPER SUPPORT (ASSY)




F25701A

Symbol meaning

REMOVAL	▲ : Remove Weld Points
INSTALLATION	⊙ : MIG Plug Weld

F25701B

REMOVAL·INSTALLATION



F25701

INSTALLATION POINT

1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
3 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.