
SMART ENTRY AND START SYSTEM


■ DESCRIPTION


- The system settings vary depending on the destinations and engine types. For details, see the equipment list in Model Outline (see page MO-42).
- The smart entry and start system not only has a wireless door lock remote control function and engine immobilizer function, but by carrying the key the following functions (entry function and push button start function) are also possible without having to use a key or transmitter button. It is an extremely convenient system.
  - The engine can be started by simply pressing the engine switch while depressing the brake pedal (Push Button Start Function)
  - Door unlock/lock (Entry Unlock/Entry Lock Functions)
  - The trunk can be opened (Trunk Open Function)
  - Wireless door lock control function.




Entry Unlock/Lock Functions







Trunk Open Function



Start Function

02KBE89TE