REAR VIEW MIRROR

■ DESCRIPTION

The functions of the rear view mirror vary depending on the destinations and grades.
For details, see the equipment list in Model Outline (see page MO-42).

Mirror	Function	Outline
Inside Rear View Mirror	Automatic Glare-Resistant EC (Electro Chromic) Mirror	The function can automatically reduce headlight glare from an on-coming vehicle during nighttime driving.
	Shift Illumination (See page BE-249)	Mounted in the lower part inside the rear view mirror, it illuminates the periphery of the shift lever during nighttime driving.
Outside Rear View Mirror	Mirror Heater (See page BE-262)	When the rear defogger switch is turned on, the mirror surface is heated for a certain period of time.
	Electric Remote Control	The outside rear view mirror can be retracted by operating the mirror switch.
	Automatic retractable function	When all doors are locked from the outside of the vehicle while the power source is ON, the outside rear view mirrors are retracted. When all doors are unlocked from the outside of the vehicle while the power source is OFF, the outside rear view mirrors are returned to their original position.
	Reverse-linked function	When the shift lever is shifted into the R position, the outside rear view mirror on the passenger side tilts downward, thus facilitating confirmation of the rearside of the vehicle.
	Memory System (See page BE-252)	The system stores up to 2 mirror positions.