



Position of Parts in Engine Compartment <LHD 2AR-FE>













- A 1 Low Pitched Horn Assembly
- A 2 Engine Hood Courtesy Switch (Hood Lock Assembly)
- A 3 Ambient Temperature Sensor (Thermistor Assembly)
- A 4 High Pitched Horn Assembly
- A 5 Front No. 1 Ultrasonic Sensor LH
- A 6 Fog Light Assembly LH
- A 7 Cooling Fan Motor
- A 8 No. 2 Cooling Fan Motor
- A 12 Front Airbag Sensor LH
- A 15 Wireless Door Lock Buzzer
- A 16 Front Speed Sensor LH
- A 17 Headlight Assembly LH
- A 18 Headlight Assembly LH
- A 19 Headlight Assembly LH
- A 20 Headlight Assembly LH
- A 21 Headlight Assembly LH
- A 22 Headlight Assembly LH
- A 23 Headlight Assembly LH
- A 24 Headlight Assembly LH
- A 25 ECM
- A 29 Windshield Wiper Motor Assembly
- A 30 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
- A 44 Security Horn Assembly
- A 49 Brake Actuator Assembly
- A 51 Headlight Cleaner Motor and Pump Assembly
- A 52 Headlight Cleaner Control Relay
- A 53 Front Speed Sensor RH
- A 54 Windshield Washer Motor and Pump Assembly
- A 55 A/C Pressure Sensor (A/C Tube & Accessory Assembly)
- A 56 Front No. 1 Ultrasonic Sensor RH
- A 57 Fog Light Assembly RH
- A 58 Front Airbag Sensor RH
- A 60 Headlight Assembly RH
- A 61 Headlight Assembly RH
- A 62 Headlight Assembly RH
- A 63 Headlight Assembly RH
- A 64 Headlight Assembly RH
- A 65 Headlight Assembly RH
- A 66 Headlight Assembly RH
- A 67 Headlight Assembly RH
- A 70 Junction Connector
- A 73 Junction Connector
- A 75 Level Warning Switch Assembly (Windshield Washer Motor and Pump Assembly)
- A 76 Headlight Assembly LH
- A 78 Headlight Assembly RH
- A 81 Front Wiper Deicer (Windshield Glass)
- A 82 Heated Windshield Defroster RH (Windshield Glass)
- A 83 Heated Windshield Defroster LH (Windshield Glass)
- A 90 Headlight Assembly LH
- A 91 Headlight Assembly LH
- A 92 Front Turn Signal Light Assembly LH
- A 93 Headlight Assembly LH
- A 94 Headlight Assembly RH
- A 95 Headlight Assembly RH
- A 96 Front Turn Signal Light Assembly RH
- A 97 Headlight Assembly RH
- A 98 Headlight Assembly LH
- A 99 Headlight Assembly RH
- A 100 Front Turn Signal Light Assembly LH

A 101 Front Turn Signal Light Assembly RH


Position of Parts in Engine Compartment <LHD 2AR-FE>




Position of Parts in Engine Compartment <LHD 2AR-FE>




(Low Halogen Type)




(Headlight Leveling Motor)




(Headlight Leveling Motor)




(High)




(Clearance Light)






(Front Turn Signal Light)



(Low HID Type)



(Headlight Swivel Motor)



Position of Parts in Engine Compartment <LHD 2AR-FE>

