















Position of Parts in Instrument Panel <RHD>








- I 72 Windshield Wiper Relay Assembly
- I 74 Glove Box Light Assembly
- I 75 Diode (Front Courtesy Light)
- I 76 Blower Motor Sub-Assembly with Fan
- I 77 A/C Amplifier Assembly
- I 78 Certification ECU
- I 82 Clearance Warning ECU Assembly
- I 83 Front No. 2 Speaker Assembly RH
- I 92 Junction Connector
- I 93 Junction Connector
- I 94 Junction Connector
- I 95 Junction Connector
- I 96 Junction Connector
- I 97 Junction Connector
- I 100 Junction Connector
- I 101 Junction Connector
- I 102 Junction Connector
- I 103 Junction Connector
- I 104 Junction Connector
- I 105 Junction Connector
- I 106 Junction Connector
- I 107 Junction Connector
- I 111 Junction Connector
- I 124 Junction Connector
- I 125 Junction Connector
- I 126 Junction Connector
- I 128 Junction Connector
- I 129 Junction Connector
- I 146 No. 1 Stereo Jack Adapter Assembly
- I 152 Radio & Display Receiver Assembly
- I 153 Radio & Display Receiver Assembly
- I 154 Radio & Display Receiver Assembly
- I 155 Radio & Display Receiver Assembly
- I 156 Radio & Display Receiver Assembly
- I 172 Yaw Rate Sensor
- I 173 Junction Connector
- I 174 Junction Connector
- I 176 Vehicle Stability Control Switch
- I 178 Back Sonar or Clearance Sonar Switch Assembly
- I 179 Vehicle Stability Control Switch
- I 181 Headlight Cleaner Switch Assembly
- I 182 Front Foot Light LH (No. 1 Interior Illumination Light Assembly LH)
- I 183 Ion Generator Assembly
- I 185 Radio & Display Receiver Assembly
- I 186 Front Foot Light RH (No. 1 Interior Illumination Light Assembly RH)
- I 204 No. 1 Stereo Jack Adapter Assembly
- I 205 Radio & Display Receiver Assembly
- I 211 Shift Position Indicator (Indicator Light Wire Sub-Assembly)
- I 213 Diode (A/T Shift)
- I 214 Diode (A/T Shift)


Position of Parts in Instrument Panel <RHD>



Position of Parts in Instrument Panel <RHD>



Position of Parts in Instrument Panel <RHD>



Position of Parts in Instrument Panel <RHD>

