


Position of Parts in Seat <LHD Except TMMK Made>

- * 1:w/ Power Seat
- * 2:w/o Power Seat
- * 3:w/ Seat Position Memory
- * 4:w/o Seat Position Memory
- * 5:Before Feb. 2015 Production
- * 6:From Feb. 2015 Production



- N 2 Front Seat Inner Belt Assembly LH

- O 3 Front Seat Inner Belt Assembly RH

- d 1 Front Power Seat Slide Position Motor RH
- d 4 Front Power Seat Switch RH
- d 6 Front Seat Heater Control Sub-Assembly RH
- d 7 Junction Connector
- d 22 Front Seat Heater Control Sub-Assembly RH

- e 1 Front Power Seat Slide Position Motor LH
- e 2 Front Power Seat Tilt Position Motor LH
- e 3 Front Power Seat Lift Position Motor LH
- e 4 Front Power Seat Switch LH
- e 5 Front Power Seat Lumbar Switch LH
- e 6 Front Seat Heater Control Sub-Assembly LH
- e 7 Junction Connector
- e 8 Front Power Seat Slide Position Motor LH
- e 9 Front Power Seat Tilt Position Motor LH
- e 10 Front Power Seat Lift Position Motor LH
- e 11 Position Control ECU Assembly LH (Front Power Seat Switch LH)
- e 12 Position Control ECU Assembly LH (Front Power Seat Switch LH)
- e 13 Front Seat Heater Control Sub-Assembly LH

- f 1 Front Power Seat Reclining Position Motor RH

- g 1 Front Power Seat Reclining Position Motor LH
- g 2 Front Power Seat Lumbar Support Motor LH
- g 3 Power Seat Reclining Motor LH
- g 4 Power Seat Lumbar Support Motor LH

- z 10 Front Seat Airbag Assembly LH
- z 11 Front Seat Airbag Assembly RH

Position of Parts in Seat <LHD Except TMMK Made>

