






I64(A), I65(B), I66(C), I67(D), I147(E)
Navigation Receiver Assembly



* 5 : Before Sep. 2013 Production

* 6 : From Sep. 2013 Production


I64(A), I65(B), I66(C), I67(D), I147(E)
Navigation Receiver Assembly




I146
No. 1 Stereo Jack Adapter Assembly


: There is no wire color information.

I64(A), I65(B), I66(C), I67(D), I147(E)
Navigation Receiver Assembly











A 42
Black




A 49
Black




A 70
White




E 4
Gray




E 76
White




E 85
Gray




I 2
White




I 18
Black




I 28
Black




I 29
Blue




I 60
White




I 64
White




I 65
White




I 66
White




I 67
White




I 68
White




I 69
White



I 84
White




I 93
White




I 97
White




I101
White




I105
White




I107
White




I124
White




I125
Gray



I146
Black



I147
Gray




J 5
Black




K 5
Black




N 41
White



O 19
White




O 20
White












O 22
Black




S 7
White







IA3
Blue




IA4
Gray




IA8
Gray




II1
White




IO3
Gray




IS1
White




JI1
Gray




KI1
White



NI1
White



NX1
White



TN2
White

