








- * 1 : w/ Stereo Component Amplifier Assembly
- * 2 : w/o Stereo Component Amplifier Assembly
- * 3 : w/ Radio & Display Receiver Assembly
- * 4 : w/ Radio Receiver Assembly
- * 6 : w/ Navigation System
- * 7 : w/o Navigation System









A 49
Black




I 18
Black




I 47
Yellow




I 68
White




I 69
White




I 84
White




I124
White














I128
White




I148
White







IA3
Blue




IA4
Gray




IA8
Gray



IS1
White



IS2
White



OI2
Black

