














Position of Parts in Instrument Panel <Before Dec. 2013 Production>




- | 1 Front No. 2 Speaker Assembly LH
- | 2 Front No. 2 Speaker Assembly LH
- | 3 Power Management Control ECU
- | 4 Power Management Control ECU
- | 5 Back Sonar or Clearance Sonar Switch Assembly
- | 10 Blind Spot Monitor Main Switch (Warning Canceling Switch Assembly)
- | 12 Main Body ECU
- | 13 Main Body ECU
- | 17 Combination Meter Assembly
- | 18 Combination Meter Assembly
- | 24 Steering Lock Actuator Assembly
- | 25 Headlight Dimmer Switch Assembly
- | 27 Spiral Cable Sub-Assembly
- | 28 Spiral Cable Sub-Assembly
- | 29 Steering Sensor
- | 31 Windshield Wiper Switch Assembly
- | 32 Windshield Wiper Switch Assembly
- | 39 Data Link Connector 3
- | 40 Lower No. 1 Instrument Panel Airbag Assembly
- | 41 Quick Heater Assembly
- | 42 Shift Lock Control ECU (Lower Shift Lever Assembly)
- | 45 Rear Power Outlet Socket Assembly
- | 46 No. 1 Indoor Electrical Key Antenna Assembly


Position of Parts in Instrument Panel <Before Dec. 2013 Production>




I 27
Yellow




I 28
Black



I 29
Blue




I 31
White




I 32
White




I 39
White




I 40
Black




I 41
White



I 42
White



I 45
White



I 46
White

