


Position of Parts in Body



- P 1 Rear Window Defogger (Back Window Glass)

- S 3 Humidity Sensor (A/C Thermistor Assembly)
- S 4 Sliding Roof Control ECU (Sliding Roof Drive Gear Sub-Assembly)
- S 5 Vanity Light Assembly LH
- S 6 Visor Assembly LH
- S 8 Vanity Light Assembly RH
- S 9 Visor Assembly RH
- S 11 Inner Rear View Mirror Assembly
- S 12 Roof Console Box Assembly
- S 13 No. 1 Room Light Assembly
- S 14 Spot Light Assembly LH
- S 15 Spot Light Assembly RH
- S 19 Inner Rear View Mirror Assembly
- S 20 Lane Departure Warning Camera
- S 21 Junction Connector

- T 2 License Plate Light Assembly RH
- T 3 Luggage Compartment Door Lock Assembly
- T 4 Luggage Door Opening Switch Assembly
- T 5 License Plate Light Assembly LH
- T 6 Rear Television Camera Assembly
- T 8 Rear Combination Light Assembly LH
- T 9 Rear Combination Light Assembly LH
- T 10 Blind Spot Monitor Sensor LH
- T 11 Rear Electrical Key Antenna
- T 12 Rear Combination Light Assembly RH
- T 13 Rear Combination Light Assembly RH
- T 14 Rear Electrical Key Antenna
- T 16 Junction Terminal
- T 17 Rear Light Assembly RH
- T 18 Rear Light Assembly LH
- T 23 Rear Television Camera Assembly
- T 24 Junction Connector

- U 1 Rear No. 1 Ultrasonic Sensor LH
- U 2 Rear No. 1 Ultrasonic Sensor Center LH
- U 3 Rear No. 1 Ultrasonic Sensor Center RH
- U 4 Rear No. 1 Ultrasonic Sensor RH

- V 1 Front Door Outside Handle Assembly RH























- W 1 Front Door Outside Handle Assembly LH

- h 1 Rear Speed Sensor RH

- i 1 Rear Speed Sensor LH

- z 12 Rear Seat Airbag Assembly LH
- z 13 Rear Seat Airbag Assembly RH

Position of Parts in Body



Position of Parts in Body

