
























Position of Parts in Instrument Panel



* 9:w/ Navigation Receiver Assembly
* 10:w/ Radio & Display Receiver Assembly Korea

- | 47 Airbag Sensor Assembly
- | 48 Pattern Select Switch Assembly
- | 49 ECO Switch Assembly
- | 52 Seat Heater Switch LH
- | 53 Seat Heater Switch RH
- | 54 No. 1 Clearance Warning Buzzer
- | 55 Front Power Outlet Socket Assembly
- | 56 A/C Control Assembly
- | 57 Cooler (Room Temperature Sensor) Thermistor
- | 58 Power Switch
- | 60 Front No. 3 Speaker Assembly
- | 61 Automatic Light Control Sensor
- | 62 Shift Position Indicator (Indicator Light Wire Sub-Assembly)
- | 64 Radio & Display Receiver Assembly
- | 65 Radio & Display Receiver Assembly
- | 66 Radio & Display Receiver Assembly
- | 67 Radio & Display Receiver Assembly
- | 68 Stereo Component Amplifier Assembly
- | 69 Stereo Component Amplifier Assembly
- | 71 Vehicle Approaching Speaker Controller
- | 72 Navigation Receiver Assembly
- | 73 Navigation Receiver Assembly
- | 74 Navigation Receiver Assembly
- | 75 Diode (Front Courtesy Light)
- | 76 Blower Motor Sub-Assembly with Fan
- | 77 A/C Amplifier Assembly

Position of Parts in Instrument Panel



Position of Parts in Instrument Panel

