



Position of Parts in Body (LHD)




R50	Rear Seat Airbag Assembly RH
R51	Rear Seat Airbag Assembly LH
R52	Front Seat Outer Belt Assembly RH
R53	Front Seat Outer Belt Assembly LH
R54	Rear Seat Belt Assembly Outer RH
R55	Rear Seat Belt Assembly Outer LH
R56	Curtain Shield Airbag Assembly RH
R57	Curtain Shield Airbag Assembly LH
R62	Front Power Seat Reclining Position Motor RH (Front Seat Back Frame Sub-Assembly RH)
R63	Front Power Seat Reclining Position Motor LH (Front Seat Back Frame Sub-Assembly LH)
R64	Rear Window Shade Assembly
R65	Luggage Compartment Light Assembly No. 1
R72	Rear Seat Inner with Center Belt Assembly RH
R73	Rear Seat Inner with Center Belt Assembly LH
R74	Rear Seat Inner with Center Belt Assembly LH
R100	No. 5 Junction Connector
R101	No. 6 Junction Connector
R102	Rear Seat Heater (Seat Heater Assembly)
R121	Fuel Pump Control ECU Assembly
R123	Television Camera Controller
R124	Television Camera Controller


Position of Parts in Body (LHD)




90980-12698




90980-12698




90980-12452




90980-12452




90980-12452




90980-12452




90980-12575




90980-12575




90980-10825




90980-10825




90980-12558




90980-11148



90980-12365





90980-12365





90980-12732

R100
Blue




90980-12372

R101
Blue




90980-12372

R102
White



90980-12733


R121
Black



90980-10957


Position of Parts in Body (LHD)

R123
White



90980-12760

R124
White



90980-12761