


G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel

[LHD]



A12 A/C Blower Motor Linear Controller
 A13 A/C Control Assembly
 A14 A/C Control Assembly
 A15 A/C Evaporator Temp. Sensor
 A16 A/C Room Temp. Sensor
 A17 A/C Solar Sensor
 A18 A/C SW
 A19 ABS ECU
 A20 ABS ECU
 A21 Air Inlet Control Servo Motor
 A22 Air Mix Control Servo Motor
 A23 Air Vent Mode Control Servo Motor
 A24 Airbag Squib (Front Passenger Airbag Assembly)
 A25 Airbag Squib (Steering Wheel Pad)

B 3 Blower Motor
 B 4 Blower Resistor
 B 5 Blower SW
 B 6 Body ECU
 B 7 Body ECU
 B 8 Buckle SW LH
 B 9 Buckle SW RH
 C 6 Center Airbag Sensor Assembly
 C 7 Center Airbag Sensor Assembly
 C 8 Center Airbag Sensor Assembly
 C 9 Cigarette Lighter
 C10 Clock
 C11 Combination Meter
 C12 Combination Meter
 C13 Combination SW
 C14 Combination SW
 C15 Combination SW