

J POWER SOURCE (Current Flow Chart)

Engine Room J/B (See Page 78)

Fuse		System	Page
7.5A	ALT-S	Charging	136
7.5A	AM2	Engine Control and Engine Immobiliser System	138
		SRS	249
		Starting and Ignition	132
7.5A	EFI NO.1	ECT and A/T Indicator	262
		Engine Control and Engine Immobiliser System	138
7.5A	EFI NO.2	Engine Control and Engine Immobiliser System	138
7.5A	HEAD LVL	Headlight Beam Level Control	160
7.5A	ST	Engine Control and Engine Immobiliser System	138
		Starting and Ignition	132
10A	HEAD LH LWR	Headlight (w/ Daytime Running Light)	152
		Headlight (w/o Daytime Running Light)	156
10A	HEAD RH LWR	Headlight (w/ Daytime Running Light)	152
		Headlight (w/o Daytime Running Light)	156
10A	HEAD LH UPR	Headlight (w/o Daytime Running Light)	156
10A	HORN	Horn	270
15A	EFI	ECT and A/T Indicator	262
		Engine Control and Engine Immobiliser System	138
15A	HAZ	Turn Signal and Hazard Warning Light (Australia)	190
		Turn Signal and Hazard Warning Light (Europe)	186
15A	IG2	Engine Control and Engine Immobiliser System	138
		Starting and Ignition	132
20A	HEAD RH UPR DRL NO.2	Headlight (w/ Daytime Running Light)	152
		Multiplex Communication System (LHD)	196
20A	HEAD RH UPR	Headlight (w/o Daytime Running Light)	156
25A	ABS NO.2	ABS	254
30A	CDS	Radiator Fan and Condenser Fan	298
30A	RDI	Radiator Fan and Condenser Fan	298
40A	ABS NO.1	ABS	254
40A	MAIN	Engine Control and Engine Immobiliser System	138
		Starting and Ignition	132
50A	HTR	Automatic Air Conditioner	300
		Manual Air Conditioner	306
120A	ALT	Charging	136
		Headlight (w/ Daytime Running Light)	152
		Illumination (w/ Daytime Running Light)	170
		Illumination (w/o Daytime Running Light)	174
		Light Reminder Buzzer	192
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Taillight	166

* These are the page numbers of the first page on which the related system is shown.

Instrument Panel J/B (See Page 80)

Fuse		System	Page
5A	ABS-IG	ABS	254
5A	BK/UP LP	Back-Up Light Combination Meter Cruise Control ECT and A/T Indicator Engine Control and Engine Immobiliser System	182 292 258 262 138
5A	BODY ECU-IG	Door Lock Control (LHD) Door Lock Control (RHD) Double Locking Headlight (w/ Daytime Running Light) Headlight (w/o Daytime Running Light) Interior Light Key Reminder and Seat Belt Warning Light Reminder Buzzer Moon Roof Multiplex Communication System (LHD) Multiplex Communication System (RHD) Power Window (LHD) Power Window (RHD) Wireless Door Lock Control (LHD) Wireless Door Lock Control (RHD)	226 230 234 152 156 178 246 192 244 196 208 236 240 218 222
5A	DEF RLY	Multiplex Communication System (LHD) Multiplex Communication System (RHD) Power Window (LHD) Power Window (RHD) Rear Window Defogger and Mirror Heater	196 208 236 240 286
5A	ECU-IG	Cruise Control	258
5A	FAN RLY	Radiator Fan and Condenser Fan	298
5A	TENS RDC	Cigarette Lighter and Clock Moon Roof Shift Lock (Australia)	272 244 268
5A	WARNING	ABS Automatic Air Conditioner Charging Combination Meter Cruise Control ECT and A/T Indicator Engine Control and Engine Immobiliser System Key Reminder and Seat Belt Warning Manual Air Conditioner Multiplex Communication System (LHD) Multiplex Communication System (RHD)	254 300 136 292 258 262 138 246 306 196 208

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	DOME	Cigarette Lighter and Clock	272
		Interior Light	178
		Key Reminder and Seat Belt Warning	246
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
7.5A	ECU-ACC	Cigarette Lighter and Clock	272
		Door Lock Control (LHD)	226
		Door Lock Control (RHD)	230
		Double Locking	234
		Interior Light	178
		Key Reminder and Seat Belt Warning	246
		Light Reminder Buzzer	192
		Moon Roof	244
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Power Window (LHD)	236
		Power Window (RHD)	240
		Radio and Player	290
		Remote Control Mirror (LHD)	274
		Remote Control Mirror (RHD)	276
		Wireless Door Lock Control (LHD)	218
		Wireless Door Lock Control (RHD)	222
7.5A	ECU-B	Automatic Air Conditioner	300
		Combination Meter	292
		Interior Light	178
		Manual Air Conditioner	306
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
7.5A	MPX-B	Door Lock Control (LHD)	226
		Door Lock Control (RHD)	230
		Double Locking	234
		Headlight (w/ Daytime Running Light)	152
		Headlight (w/o Daytime Running Light)	156
		Interior Light	178
		Key Reminder and Seat Belt Warning	246
		Light Reminder Buzzer	192
		Moon Roof	244
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Power Window (LHD)	236
		Power Window (RHD)	240
		Wireless Door Lock Control (LHD)	218
		Wireless Door Lock Control (RHD)	222

* These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
7.5A	OBD	Engine Control and Engine Immobiliser System	138
7.5A	PANEL 1	Illumination (w/o Daytime Running Light)	174
7.5A	PANEL 2	Combination Meter	292
		Front Fog Light	162
		Illumination (w/o Daytime Running Light)	174
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
7.5A	RR FOG	Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Rear Fog Light	164
7.5A	SRS-IG	SRS	249
7.5A	TURN	Turn Signal and Hazard Warning Light (Australia)	190
		Turn Signal and Hazard Warning Light (Europe)	186
10A	HTR	Automatic Air Conditioner	300
		Manual Air Conditioner	306
		Rear Window Defogger and Mirror Heater	286
10A	MIR HTR	Rear Window Defogger and Mirror Heater	286
10A	STOP	ABS	254
		Cruise Control	258
		ECT and A/T Indicator	262
		Engine Control and Engine Immobiliser System	138
		Shift Lock (Australia)	268
		Stop Light	184
10A	TAIL	Headlight (w/ Daytime Running Light)	152
		Illumination (w/ Daytime Running Light)	170
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Rear Fog Light	164
		Taillight	166
15A	CIG	Cigarette Lighter and Clock	272
15A	FR FOG	Front Fog Light	162
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
15A	RADIO	Radio and Player	290
15A	RR WIPER	Rear Wiper and Washer	282
15A	S/ROOF	Moon Roof	244
15A	WASHER	Front Wiper and Washer	278
		Rear Wiper and Washer	282
20A	DOOR	Door Lock Control (LHD)	226
		Door Lock Control (RHD)	230
		Double Locking	234
		Interior Light	178

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
20A	DOOR	Key Reminder and Seat Belt Warning	246
		Light Reminder Buzzer	192
		Moon Roof	244
		Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Power Window (LHD)	236
		Power Window (RHD)	240
		Wireless Door Lock Control (LHD)	218
		Wireless Door Lock Control (RHD)	222
20A	FL P/W	Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Power Window (LHD)	236
		Power Window (RHD)	240
20A	FR P/W	Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Power Window (LHD)	236
		Power Window (RHD)	240
25A	WIPER	Front Wiper and Washer	278
30A	DEF	Multiplex Communication System (LHD)	196
		Multiplex Communication System (RHD)	208
		Rear Window Defogger and Mirror Heater	286

Engine Room R/B No.2 (See Page 83)

Fuse		System	Page
10A	HEAD LH UPR	Headlight (w/ Daytime Running Light)	152
10A	HEAD RH UPR	Headlight (w/ Daytime Running Light)	152

* These are the page numbers of the first page on which the related system is shown.

