


E ELECTRICAL WIRING ROUTING

Position of Parts in Body

[RHD]



* 1: Except Australia
* 2: Australia
* 3: w/ Moon Roof

A26 ABS Speed Sensor Rear LH
A27 ABS Speed Sensor Rear RH

B10 Back Door Lock Motor

D 2 Door Control Receiver
D 3 Door Courtesy SW LH
D 4 Door Courtesy SW RH
D 5 Door Key Lock and Unlock SW LH
Door Lock Detection SW LH
Door Lock Motor LH
D 6 Door Key Lock and Unlock SW RH
Door Lock Detection SW RH
Door Lock Motor RH
D 7 Door Side Airbag Sensor LH
D 8 Door Side Airbag Sensor RH

F13 Front Door Speaker LH
F14 Front Door Speaker RH
F15 Front Door Tweeter Speaker LH
F16 Front Door Tweeter Speaker RH
F17 Fuel Pump
Fuel Sender

H13 High Mounted Stop Light
H20 Height Control Sensor

J 3 Junction Connector
J 12 Junction Connector
J 14 Junction Connector
J 15 Junction Connector
J 16 Junction Connector

L 1 License Plate Light LH
L 2 License Plate Light RH
L 3 Luggage Compartment Light
L 4 Luggage Compartment Light SW

M 1 Moon Roof Control Relay and Motor
M 2 Moon Roof Control SW
Personal Light