
F RELAY LOCATIONS

(2) : No. 2 Engine Room Relay Block ⬭ : No. 2 Engine Room Junction Block	**Floor Panel**



(2) : No. 2 Engine Room Relay Block ⬭ : No. 2 Engine Room Junction Block	**Floor Panel**

Unit A

* 10:30A (2TR-FE)
15A (Except 2TR-FE)

