

Engine Room
Main Wire
AB
AA
CG
CH
Blower Motor
Lead Wire
BB
Air Conditioning
Wiring Harness
Sub-Assembly
Light Wire
Sensor Wire
CA
Engine Wire
No. 4 Roof Wire
No. 2 Engine Wire