

B23
B24
C2
C6
a1
s7
a5
s6
a2
r3
r6
r7
B9
b2
C1
B11
B26
B14

B 9 Engine Oil Level Sensor
B 11 Starter Assembly
B 14 Speed Meter Sensor
B 23 Injection or Supply Pump Assembly
B 24 Back-Up Light Switch Assembly
B 26 Exhaust Brake Neutral Switch Assembly

C 1 Starter Assembly
C 2 Battery
C 6 Battery

a 1 Headlight Assembly RH
a 2 Headlight Assembly LH
a 5 Low Pitched Horn Assembly

b 2 Air Cleaner Warning Sensor

r 3 Condenser Blower Motor Assembly
r 6 Condenser Blower Motor Assembly
r 7 No. 1 Pressure Switch

s 6 Rear Heater Blower Resistor
s 7 Blower Motor with Fan Sub-Assembly

B 9
White


(Except 14B 1HZ)

B 9
Gray


(14B, 1HZ)

B 11
Black



(Except 14B)


B 11
Gray



(14B)


B 14
Black



B 23
Gray


B 24
Gray


B 26
Gray


C 1



C 2



C 6



a 1
Gray



a 2
Gray



a 5
Black


b 2
Gray


r 3
Black


r 6
Black


r 7
Black


s 6
Black


s 7
White
