

Instrument Panel Wire
JB
JD
No. 2 Instrument Panel Wire
FA
No. 2 Roof Wire
No. 1 Roof Wire
FB
JA
Engine Room Main Wire
Cowl Wire
Engine Room Main Wire
No. 3 Cowl Wire
No. 2 Cowl Wire LH
Radio Wire
JC