



J1
J2
J23
J17
J16
J13
J40
J14
J26
J30
J31
J45
J15
J24
J21
J22
J46
J20
J36
J12

J 1 Combination Meter Assembly
J 2 Combination Meter Assembly
J 12 Air Conditioning Amplifier Assembly
J 13 Cooler Control Switch Assembly
J 14 Front Heater Blower Case Sub-Assembly
J 15 Blower Resistor
J 16 Heater Blower Switch
J 17 Rear Heater Blower Switch
J 20 No. 1 Power Outlet Socket Assembly
J 21 No. 1 Room Light Switch Assembly
J 22 No. 2 Room Light Switch Assembly
J 23 Hazard Warning Signal Switch Assembly
J 24 Rear Window Defogger Switch Assembly
J 26 Door Control Switch
J 30 DPF Switch Assembly
J 31 Headlight Leveling Switch
J 36 No. 2 CAN Junction Terminal
J 40 Turn Signal Flasher Assembly
J 45 DLC3
J 46 Tachograph Assembly

J 1
White




J 2
White




J 12
Black




J 13
Gray




J 14
White




J 15
White




J 16
White




J 17
Black




J 20
White




J 21
Gray




J 22
Black




J 23
Black




J 24
Black




J 26
White




J 30
Gray




J 31
Black




J 36
White



J 40
Black



J 45
Black



J 46
White

