

Engine Wire
AB
Engine Room Main Wire
No. 4 Engine Wire
No. 3 Engine Wire
No. 2 Engine Wire
Sensor Wire
CG
CH
BA
AA
BB
Blower Motor Lead Wire
No. 5 Engine Wire
No. 3 Engine Wire
Light Wire
Air Conditioning Wiring Harness Sub-Assembly
BD
AC
CC
To Solenoid Wiring
No. 4 Roof Wire
No. 2 Engine Wire