

Engine Wire
Blower Motor Lead Wire (*2)
Air Conditioning Wiring Harness Sub-Assembly
Blower Motor Lead Wire (*1)
Frame Wire
No. 4 Roof Wire
Engine Room Main Wire
No. 2 Engine Wire
No. 4 Cowl Wire
CG
Frame Wire
BA
CH
BB
No. 4 Engine Wire
No. 5 Engine Wire
No. 3 Engine Wire
Light Wire
No. 3 Engine Wire
* 1:Except Australia
* 2:Australia
To Solenoid Wiring
BD
AC
CC
AA
AB
No. 2 Engine Wire