


* 5:Before Aug. 2019 Production
* 6:From Aug. 2019 Production
* 7:N04C-WA
* 9:Before Jan. 2021 Production
* 10:From Jan. 2021 Production
* 11:N04C-VJ
A4
A44
(*11)
A129
(*7)
A110
(*11)
A130
(*7)
A111
A43
A112
A114
(*11)
A131
(*7)
A113
A45
A30
A35
A107
A106
A105
A103
A100
A88
A102
A108
A33
A67
(*5)
A27
(*6)
A101
A70
A68
A119
(*10)
A126
(*10)
A123
(*10)
A36
A37
h1
A71
A91
A14
A84
A38
A7
A40
A25
A6
A116
A121
A122
A46
A23
A24
A26

A 4 Exhaust Brake Solenoid with Bracket Assembly
A 6 Vacuum Warning Switch Assembly
A 7 Vacuum Warning Switch Assembly
A 14 Door Control Switch Assembly
A 23 Automatic Door Regulator Motor Assembly
A 24 Automatic Door Regulator Motor Assembly
A 25 Step Light Assembly
A 26 Step Light Assembly
A 27 Buzzer Assembly
A 30 Level Warning Switch
A 33 Battery Relay
A 35 Battery
A 36 Side Turn Signal Light Assembly RH
A 37 Side Marker & Reflector Light Assembly RH
A 38 Side Turn Signal Light Assembly LH
A 40 Side Marker & Reflector Light Assembly LH
A 43 Differential Pressure Sensor Assembly
A 44 No. 2 Exhaust Gas Temperature Sensor
A 45 No. 4 Exhaust Gas Temperature Sensor
A 46 Vacuum Sensor Assembly
A 67 Automatic Door Buzzer (Wireless Door Lock Buzzer)
A 68 Front Seat Outer Belt Assembly RH
A 70 Front Door Courtesy Light Switch Assembly
A 71 Skid Control ECU Assembly
A 84 No. 7 Junction Connector
A 88 No. 11 Junction Connector
A 91 No. 3 CAN Junction Connector
A 100 No. 77 Junction Connector
A 101 Buzzer Assembly
A 102 Diode (Auto Door Buzzer)
A 103 Diode (CTY)
A 105 Automatic Door Door Control Relay Assembly No. 2
A 106 Automatic Door Door Control Relay Assembly No. 2
A 107 Automatic Door Door Control Relay Assembly No. 2
A 108 No. 78 Junction Connector
A 110 No. 4 Exhaust Gas Temperature Sensor
A 111 Exhaust Gas Temperature Sensor
A 112 No. 2 Exhaust Gas Temperature Sensor
A 113 No. 5 Exhaust Gas Temperature Sensor
A 114 Urea Injector Assembly
A 116 No. 1 Nitrogen Oxides Sensor
A 119 No. 5 CAN Junction Terminal
A 121 No. 2 CAN Junction Connector
A 122 No. 6 CAN Junction Connector
A 123 No. 7 CAN Junction Connector
A 126 No. 6 CAN Junction Terminal
A 129 No. 5 Exhaust Gas Temperature Sensor
A 130 Exhaust Gas Temperature Sensor
A 131 Nitrogen Oxides Sensor

h 1 Solenoid (SLT) Valve


A 4
Gray



A 6
Gray



A 7



A 14
Gray




A 23
Gray




A 24
Dark Gray




A 25
White



A 26
White




A 27
Gray




A 30
Gray




A 33
Black




A 35




A 36
Gray




A 37
Gray




A 38
Gray



A 40
Gray



A 43
Black




A 44
Dark Gray




A 45
Dark Gray




A 46
Black



A 67
Gray




A 68
Black




A 70
White




A 71
Black




A 84
Gray




A 88
White




A 91
Dark Gray



A100
White




A101
Black




A102
Black




A103
Black




A105
White




A106
White



A107
White



A108
Black



A110
Black



A111
Dark Gray



A112
Black




A113
Dark Gray




A114
Gray




A116
Black




A119
White




A121
Dark Gray




A122
Dark Gray



A123
Black



A126
White




A129
Black



A130
Dark Gray



A131
Black



h 1
Black

