


B92
B45
(*3,*4)
B27
B47
(*7,*11)
B18
B147
B123
B143
B48
B141
(*7)
B5
B146
B131
B24
B13 (*7,*11)
B18 (*3,*4)
B93 (*11)
B140 (*7)
B3 (*4,*7,*11)
B4 (*3)
B16
B50 (*3,*4)
B51 (*7,*11)
B148
B52 (*7,*11)
B52 (*3,*4)
B5 (*3,*4)
B130
B25
B22
B15
B14
B139
B20
* 3:N04C-UH
* 4:N04C-VL
* 7:N04C-WA
* 11:N04C-VJ
B98
B96
B95
B97
B5 (*11)
B8
B118
B2 (*3)
B1 (*4 ,*7,*11)
B9
B27 (*7,*11)
B99
B13 (*3)
B144 (*7)
B156 (*11)
B21
B135
B19
B137
B138

B 1 Front Speed Sensor LH
B 2 Front Speed Sensor LH
B 3 Front Speed Sensor RH
B 4 Front Speed Sensor RH
B 5 Crank Position Sensor
B 8 Fuel Temperature Sensor
B 9 Engine Oil Level Sensor
B 13 Intake Air Temperature Sensor
B 14 Speed Meter Sensor
B 15 Speed Meter Sensor
B 16 Generator Assembly
B 18 Turbo Pressure Sensor
B 19 Transmission Solenoid (Transmission Wire)
B 20 Transmission Revolution Sensor
B 21 Park/Neutral Position Switch Assembly
B 22 Engine Oil Temperature Sensor
B 24 Back-Up Light Switch Assembly
B 25 Exhaust Brake Neutral Switch Assembly
B 27 Throttle Position Sensor
B 45 Solenoid (SLT) Valve
B 47 EGR Cooler Sub-Assembly
B 48 EGR Valve Assembly
B 50 Intake Mass Air Flow Meter Sub-Assembly
B 51 Intake Mass Air Flow Meter Sub-Assembly
B 52 Suction Control Valve
B 92 Fuel Pressure Sensor
B 93 Fuel Pressure Sensor
B 95 Injector Driver
B 96 Injector Driver
B 97 Injector Driver
B 98 Injector Driver
B 99 Starter Assembly
B 118 No. 5 CAN Junction Connector
B 123 Glow Plug Assembly
B 130 Speed Sensor
B 131 Temperature Sensor
B 135 Park/Neutral Position Switch Assembly
B 137 Transmission Solenoid (Transmission Wire)
B 138 Transmission Solenoid (Transmission Wire)
B 139 Speed Sensor
B 140 Fuel Pressure Sensor (Common Rail Assembly)
B 141 No. 3 Exhaust Gas Temperature Sensor
B 143 Pressure Discharge Valve Assembly (Common Rail Assembly)
B 144 Fuel Addition Cut Valve Assembly
B 146 No. 2 Fuel Pressure Sensor
B 147 No. 6 Exhaust Gas Temperature Sensor
B 148 Intake Air Temperature Sensor
B 156 Fuel Addition Cut Valve Assembly


B 1
Black



B 2
Gray



B 3
Black



B 4
Gray



B 5
Black



B 8
Dark Gray



B 9
White



(Except 14B 1HZ)

B 9
Gray



(14B, 1HZ)

B 13
Dark Gray




B 14
Black




B 15
Black




B 16




B 18
Black




B 19
White




B 20
Black




B 21
Gray



B 22
White



B 24
Gray



B 25
Gray




B 27
Black




B 45
Black




B 47
Black




B 48
Dark Gray



B 50
Black




B 51
Black




B 52
Gray




B 92
Black




B 93
Gray




B 95
Black



B 96
Black



B 97
Black




B 98
Black




B 99
Black




B118
Dark Gray




B123




B130
Black




B131
White




B135
Black




B137
Gray




B138
Gray



B139
Black




B140
Black




B141
Dark Gray



B143
Gray



B144
Black



B146
Dark Gray



B147
Black



B148
Gray



B156
Gray

