

(Cont. next page)




∗ 2 : w/ Multiplex Communication System (CAN)
∗ 3 : w/o Multiplex Communication System (CAN)
∗ 4 : 2TR–FE
∗ 5 : N04C–UH, N04C–VL, N04C–VQ
∗ 6 : ∗4 ∗2, LHD ∗5 ∗2
∗ 7 : 1HZ
∗ 8 : 14B
SRS
5
6
7
8
(IG)
(BAT)
5A METER–IG2
15A DOME
7. 5A GLOW NO. 2
J77(A), J78(B) No. 28 Junction Connector
J91 No. 63 Junction Connector
JF3 (LHD)
JF3 (RHD)
A/B
IG+
B
IG
SRS
CPU
CAN Controller
CAN I/F
CANH
CANL
ES
J1(A), J2(B) Combination Meter Assembly
Multiplex Communication System (CAN)<2–4>
J81(A) No. 67 Junction Connector
J86(B) No. 59 Junction Connector
AJ4 (LHD)
AJ2 (RHD)
BA5
AB1 (∗8)
AB2 (∗7)
AB7 (∗4)
BB