
D RELAY LOCATIONS

① : R/B No. 1	Lower Section of Instrument Panel in Front of Passenger's Seat (See Page 21)



*1: 30A FR-HEATER
(for Medium Current)
*2: 30A FUEL HEATER
(for Medium Current)