FOREWORD

This wiring diagram has been prepared to provide information on the electrical system of the TOYOTA COASTER.

Applicable models: HZB50 Series
BB42 Series
BB40 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
• COASTER Chassis and Body Repair Manual	RM339E
• COASTER New Car Features	NCF094E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

English
Français
Español