FOREWORD

This supplement provides information covering changes in the electrical system specifications of the COASTER which were made in Jul., 1999.

Applicable models: RZB40, 50 Series
HZB50 Series
BB42, 43, 50, 58 Series

For information which is not mentioned in this manual, please refer to the following Electrical Wiring Diagram Manuals:

Manual Name	Pub. No.
● COASTER Electrical Wiring Diagram	EWD172Y
● COASTER Electrical Wiring Diagram Supplement	EWD199Y
● COASTER Electrical Wiring Diagram Supplement	EWD238Y
● COASTER Chassis and Body Repair Manual Supplement	RM705E
● 3RZ–FE Engine Repair Manual Supplement	RM707E
● 1HZ Engine Repair Manual Supplement	RM708E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.