
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness
II2	Instrument Panel No.2 Wire and Cowl Wire
IJ1	Engine Room Main Wire and Cowl Wire
IJ2	
IJ3	
IJ4	
IJ5	
IK1	Roof Wire and Cowl Wire
Im1	Thermo Sensor Wire and Lamp Wire
Im2	