

(Cont. next page)
Air Conditioner (Gasoline Engine)
Power Source
36 COASTER
J9 JUNCTION CONNECTOR
See Illumination System<13–4>
A23 AIR VENT MODE CONTROL SERVO MOTOR
A22 AIR INLET CONTROL SERVO MOTOR
MODE SELECTION SW
A8 A/C CONTROL SW
BLOWER SW
TEMP. CONTROL
OFF
LO
M1
M2
HI
FRESH
RECIRCU
15A A. C
I 3 IGNITION SW
ACC
IG1
ST1
AM1
F16 FUSE BLOCK
60A AM1
100A ALT
60A A/C FAN
FL MAIN 3. 0W
BATTERY

36 COASTER (Cont' d)

